

INSTRUCTIONS

16 HOUR WESTMINSTER CHIME

HOW TO USE YOUR WESTMINSTER CHIMING CLOCK

- Your clock has been calibrated at our factory, all you need to do is place the 4 “AA” size Duracell batteries in the back of the clock where the battery slots are, please check that you have correctly put them in the right way.
- The chimes will automatically turn off between 22:00 hours (10PM) and come back on at 06:00 hours. This is why we call it a 16 hour chiming clock.
- In the event that the chimes do not chime the correct time on the hour and or needs to be calibrated because of daylight savings, all you need to do is open the back of the clock, and on your left hand side you will see a red button located near the speaker. You can only advance the chime by 1 hour, each time you press the red button. Remembering that you will not hear the chimes after 22:00 hours. If your clock is not chiming between 10:00 hours and 18:00 hours (6PM) you will need to advance the clocks time by 12 hours.

THIS PRODUCT COMES WITH OUR LIFETIME GUARANTEE

REFER TO LIFETIME GUARANTEE TERMS AND CONDITIONS